


1. Baler Frame



Baler

Where to find the Serial Number (SN)

- 1. Stamped in Baler Frame
- 2. Name plate on Baler Frame (SN & Model #)
- 3. Stamped in Autoty Inserter Cabinet
- 4. In Control Panel (3 places)
 - a) above disconnect
 - b) UL label number tied to SN
 - c) on drawings
- 5. On the Manual Cover

